Extend and ExtendPlus Cover

ExtendPlus and Extend Service Contracts allow the duration of the standard warranty to be extended either for the full vehicle (ExtendPlus), or just the driveline (Extend). They provide cover for mechanical, electronic and electrical components that form part of the UK vehicle's standard specification that fail during the warranty period.

The table below illustrates, at a glance, what's included in both types of cover:

| | Extend (driveline only) | ExtendPlus (full vehicle) |
|--------------------------------------|-------------------------|---------------------------|
| Roadside Assistance and Recovery | | • |
| Mercedes-Benz Uptime | | |
| Engine | | |
| Complete engine | • | • |
| Compressor | • | • |
| Alternator/starter | • | • |
| Fuel pump | • | • |
| Water pump | • | • |
| Turbo | • | • |
| Viscous fan ¹ | • | • |
| Engine brakes | • | • |
| Fuel injection system | • | • |
| Manifolds | • | • |
| Clamps, hoses etc. ² | • | • |
| Oil seals, gaskets ² | • | • |
| Casings | • | • |
| Exhaust after treatment ¹ | | • |
| Radiator/shutter | | • |
| Charge air cooler | | • |
| Steering pump | | • |
| A/C compressor | | • |
| Filters | | |
| Drive belts | | |
| Drive | | |
| Complete gearbox | • | • |
| Gears, shafts, bearings, synchros | • | • |
| Pumps | • | • |
| Retarder | • | • |
| Range change | • | • |
| Turbo retarder clutch | • | • |
| Oil cooler | • | • |
| Torque converter | • | • |
| Clamps, hoses etc. ² | • | • |
| Oil seals, gaskets | • | • |
| Casings | • | • |
| Shift mechanism, linkage | | • |
| Speedo drive | | • |
| Release bearing, driven plate | | • |
| Master/slave cylinder | | • |
| Flywheel | | • |
| Clutch plate | | |

¹ Excluding servicable items subject to routine works

² Only as part of major assembly repair

□ Optional Cover





| | Extend (driveline only) | ExtendPlus (full vehicle) |
|--|-------------------------|---------------------------|
| Axles | | |
| Crown wheel/pinion planet gears | • | • |
| Propellor shafts/intermediate bearing/half shafts | • | • |
| Diff lock | • | • |
| Driven front axle hydraulic pump | • | • |
| Driven front axle hydraulic control unit | • | • |
| Driven front axle hub and bearing | • | ٠ |
| Clamps, hoses etc. ² | • | ٠ |
| Dil seals, gaskets | • | ٠ |
| Casings | • | ٠ |
| Non driven axle hubs, bearings, tie rods, drag links | | • |
| Air bellows | | • |
| Shock absorbers | | • |
| Stabiliser bar | | • |
| Leaf springs | | |
| Chassis | | |
| Compressed air system | | • |
| Steering gear/shaft/steering box | | • |
| Fuel system ¹ | | • |
| Brake calipers (excluding seized components) | | • |
| Viring | | • |
| Electrical sensors, modules | | • |
| Brake linings | | |
| Brake disc/drum | | |
| Battery | | |
| ight source | | |
| Exhaust system | | |
| Cab | | |
| Safety systems | | • |
| Electrical and instruments | | • |
| Heating systems | | • |
| Wiper systems | | • |
| Seats (excluding covers) | | • |
| Navigation/audio | | • |
| Wiper blades | | • |
| | | |
| Light source | | |
| Body | | |
| Electrical Components | | |
| | • | • |
| Engine control unit Sensors | • | • |
| Vodules | | • |
| ECU | | • |
| | | • |
| Relays | | • |

¹ Excluding servicable items subject to routine works

² Only as part of major assembly repair
D optional Cover



